

How to Clean

- ◆ Clean the product on the same day after every use.
- ◆ Use mild kitchen detergent (for table or cookware).
- ◆ Use a soft sponge or cloth.
- ◆ Clean the product thoroughly to prevent any odor.

- ① Wash each part using a sponge with diluted detergent water or lukewarm water, and then thoroughly rinse it with water.
- ② Wipe the water off with a dry cloth and dry the parts thoroughly.
 - ※ The body or inner stopper can not be disassembled.

Caution


- Do not soak the main body and stopper when washing them. (Water may enter the main body and stopper.)
- Do not use thinners, cleansers, bleaches, cleaning wipes, metallic scrubbing brushes, or nylon scrubbing brushes.
- Do not use a dishwasher or dish dryer, and do not wash with boiling water.
- Be sure to attach the stopper and stopper gasket.
- When the product is not to be used for a long period of time, thoroughly wash off any marks and then dry it.

Attaching and removing the gasket

Attach the gasket fully and securely.

Caution

- When attaching the gasket, check its position and direction. Contents may leak.



Countermeasure against staining inside the main body

For red, rust-like spots or rough areas

Such staining can be caused by minerals in water, such as calcium, magnesium, and iron. It is recommended to clean with citric acid, which is available at supermarkets and drugstores.

- (1) Dilute the citric acid (approximately 10 g) in lukewarm water, and then pour it into the main body.
- (2) After a few hours have elapsed, wash the main body with a soft brush and then thoroughly rinse it.
- (3) Dry the main body completely.

MSK-A

Replacing and Purchasing Consumable Parts

The gasket and lid are consumable parts. Check once a year for damage/deterioration. If heavily stained or loose, replace them. For replacement parts, contact customer service or the shop where you purchased this product.

Before Contacting Customer Service

The utmost measures have been taken to ensure the quality of this product. Should the product be defective, however, contact your dealer and provide the following information.

1. Product name
2. Model Number
3. Description of trouble (As detailed as possible)
4. Purchase date

Feel free to send any questions or comments about this product to the shop where you purchased it.

※ For the purpose of performance improvement, designs, specifications and parts shown in this publication are subject to change without notice.

Specifications

Model No.	MSK-A030
Capacity	0.30L / 10.1 oz
Heat retention	Greater than 85°C • 185°F (1 hour) Greater than 66°C • 150°F (6 hours)
Cold retention	Less than 9°C • 49°F (6 hours)
Size*	W 7.1 x D 7.1 x H 20.8 cm W 2.80 x D 2.80 x H 8.19 in
Weight*	0.24kg / 0.53 lbs

* Approximate value

※ Heat retention has been calculated under the condition of adding hot water at 95°C ±1°C • 203°F±2°F and leaving it in a room temperature of 20°C±2°C • 68°F±4°F for 1 hour or 6 hours.

※ Cold retention has been calculated under the condition of adding cold water at 4°C ±1°C • 39°F±2°F and leaving it in a room temperature of 20°C±2°C • 68°F±4°F for 6 hours.

※ Capacity is the actual volume of water that can be stored into the product when the spout is closed. This is not the "Maximum level" volume described in "Safety Precautions".



TIGER CORPORATION

Head Office: 3-1 Hayami-cho, Kadoma City, Osaka 571-8571, Japan

TIGER CORPORATION HONG KONG LIMITED

Rm. 1006B, 10/FI., Join-in Hang Sing Centre, 71 - 75 Container Port Road, Kwai Chung, N.T.

Tel: (852) 2418-0912 Fax: (852) 2418-0911

URL : <http://tiger-corporation.hk/>

TIGER CORPORATION U.S.A.

1815 W 205th Street, Unit 106, Torrance, CA 90501

Tel: 1-866-55-TIGER (84437)

Email: support@japantigercorp.com

URL : <https://tiger-corporation-us.com/>